





CONVERSION KIT PB/CK/119 FOR PB/29

The conversion kit replaces the setting plate on the planer. The adjustment plate supplied with some planer models can then be fitted to the conversion kit, which separates the cutting edge from the block. When the blade is fitted the assembled part can be adjusted following the planer manufacturers instruction manual.



For Ryobi L1323A,
HL-82 Old Makita1900B



For Makita 1100, 1125, 1900, 1923B

For Hitachi F20, FU20

INTENDED USE

This conversion kit set is intended to be used in certain portable power planers to allow PB/29 to be fitted.

INSTRUCTIONS

Unplug machine when fitting blades or undertaking any maintenance. Never use dull blades. Always refer to manufacturers instructions when making adjustments and when using power planers.

Fitting Reversible Blades:

1. Undo securing bolts half to one turn & slide out blade.
2. Fit new blade & push blade back into its correct seating position.
3. Check side clearance & tighten securing bolts.
4. Check blades are level to back shoe of planer.
5. Re-check tightness of securing bolts.
6. Rotate block to ensure blades do not foul.

5 PB/CK/119



Trend Machinery & Cutting Tools Ltd.

Technical Support: 0044(0)1923 224681
technical@trendm.co.uk
www.trend-uk.com

C/PB/CK/119 v1.0

trend[®]
routing technology