

Please use only Trend original spare parts.

T35 - SPARE PARTS LIST			v2.0 06/2017
No.	Qty.	Desc.	Ref.
1	1	Handle	WP-T35/001
2	1	Motor Housing	WP-T35/002
3	2	Container Catch	WP-T35/003
4	1	Indicator Light	WP-T35/004
5	1	Air Outlet Grid	WP-T35/005
6	1	Switch	WP-T35/006
7	1	Switch Panel	WP-T35/007
8	1	Auto Start Socket 240V UK Plug, Cover and Spacer	WP-T35A/008
	1	Auto Start Socket 115V UK Plug and Cover	WP-T35AL/008
	1	Auto Start Socket 230V Euro Plug and Cover	WP-T35EUR/008
9	1	On/Off Dial	WP-T35/009
10	1	Cage	WP-T35/010
11	1	Float	WP-T35/011
12	1	Pressure Switch	WP-T35/012
13	1	Motor Gasket Lower	WP-T35/013
14	1	Motor with Leads 240V	WP-T35/014
	1	Motor with Leads 115V	WP-T35L/014
15	1	Motor Gasket Upper	WP-T35/015
16	1	Upper Motor Housing	WP-T35/016
17	1	Shaker Solenoid Pump with Screws 240v (T35A & T35A/EURO)	WP-T35/017
	1	Shaker Solenoid Pump with Screws 115v (T35AL)	WP-T35L/017
18	2	Plastic Tube 478mm	WP-T31/018
19	1	Universal Spout	WP-T31/019
20	1	Creative Tool 35mm ID	WP-T31/020
21	1	Hose and Handle with Air Control Valve	WP-T31/021
22	1	3 Core Cable with Plug 240V UK	WP-T31/011
	1	2 Core Cable with Plug 230V Euro	WP-T35EUR/022
	1	3 Core Cable with Plug 115V UK	WP-T35L/022
23	1	Cable Plate	WP-T35/023
24	1	Upholstery Spout	WP-T31/024
25	1	Lower Motor Housing	WP-T35/025
26	2	Filter Clip	WP-T35/026
27	1	Power Tool Adaptor	WP-T31/027
28	1	Hose Spout 35mm OD	WP-T31/028
29	1	Circuit Board with Leads 230V	WP-T35/029
	1	Circuit Board with Leads 115V	WP-T35L/029
29A	1	Floor Spout Brush for Floors	WP-T31/029
30	1	Floor Spout Wiper for Liquids	WP-T31/030
31	1	Cage Gasket	WP-T35/031
32	6	Screw Self Tapping Pan 3.5mm x 16mm Pozi	WP-T31/032
33	1	Container Housing	WP-T35/033
34	2	Large Wheel	WP-T35/034
35	2	Castor 40mm	WP-T35/035
36	1	Anti-vibration Support	WP-T35/036
37	1	Hose 39mm x 5mm with Adaptor & Bayonet	WP-T35/037
38	8	Screw Self Tapping Pan 5mm x 32mm Pozi	WP-T35/038
39	1	Cable Gland	WP-T35/039
40	1	Container Deflector Bayonet	WP-T35/040
41	1	Hose Bayonet Fitting	WP-T35/041
42	4	Screw Self Tapping Pan 35mm x 30mm Pozi (T35A)	WP-T35/042A
	4	Machine Screw Csk M5 x 25mm Pozi (T35AL)	WP-SCW/117
	4	Screw Self Tapping Pan 3.5 x 11mm Pozi (T35A & T35/EURO)	WP-T35/042

T35 - SPARE PARTS LIST			v1.0 04/2017
43	4	Hex Nut M5 Nyloc (T35AL)	WP-NUT/27
44	2	Machine Screw M4 x 10mm Pozi	WP-SCW/68
45	1	Carbon Filter	T35/6
46	1	HEPA Filter	T35/5
47	1	Polyurethane Foam Filter	T35/4
48	1	Round Brush	T31/3
49	1	Cartridge Filter HEPA	T35/2
50	1	Micro Filter Bag	T35/1
51	1	Manual	MANU/T35

PROBLEM	SOLUTION
Motor does not start	The ON/OFF switch is not activated. Power cable is not attached to power supply. Fuse of the plug has blown requiring replacement of fuse.
Suction capacity decreases.	Remove blockages in the suction nozzle, suction tube, suction hose or filters. Replace the paper collection bag. Check for proper installation of the filters. Clean or replace the filters.
Vacuum stops running.	<ol style="list-style-type: none"> 1. Turn the vacuum off and disconnect vacuum cleaner from power source. 2. Empty the canister, if needed. 3. Allow the unit to cool. 4. Plug the power cable into an appropriate outlet and turn on/off switch to the ON position to test. If vacuum will not restart contact your seller or check the location of your nearest authorised Trend Service Agent on the website.
Dust comes out while vacuuming	Check for proper installation of the filters. Ensure filters are not damaged; replace if necessary. Ensure filter seals are in place and are secure.
No suction power during wet cleaning.	Container is full; float has closed the suction opening. Switch off cleaner and empty the tank.
Power tool does not turn on in AUTO mode.	The switch AUTO is not in position AUTO. Power tool is defective. Check that the power tool works or that the plug is inserted properly.
Airflow indicator light remains on.	Blockage or collection bag is full. Clear blockage or replace collection bag.

T35 - SPARE PARTS DIAGRAM

v2.0 06/2017

Please use only Trend original spare parts.

