

Please use only Trend original spare parts.

| T5 V2 - SPARE PARTS LIST | | | v11.0 07/2017 |
|---------------------------------|-------------|--|----------------------|
| No. | Qty. | Desc. | Ref. |
| 1 | 1 | Stator Housing | WP-T5/001 |
| 2 | 1 | Top Vent Housing | WP-T5E/002 |
| 3A | 1 | Base Complete V2 | WP-T5/003A |
| 4A | 1 | Lower Bearing Housing V2 | WP-T5/004A |
| 5 | 1 | Spring for Revolving Guide | WP-T5/005 |
| 6 | 1 | Ball for Revolving Guide | WP-T5/006 |
| 8A | 1 | Revolving Guide V2 | WP-T5/008A |
| 9 | 3 | Nut Hex M5 | WP-NUT/05 |
| 10 | 1 | Threaded Pin M5 x 15mm Revolving Guide Cheese Head | WP-T5/010 |
| 11 | 7 | Thumb Knob M6 Male x 12mm | WP-T5/011 |
| 12A | 1 | Revolving Guide Stepped Screw M6 | WP-T5/012A |
| 13 | 1 | Threaded Pin M5 x 20mm Cheese Head | WP-T5/013 |
| 14 | 1 | Depth Stop | WP-T5/014 |
| 15A | 2 | Grip Knob V2 | WP-T5/015A |
| 16 | 7 | Spring 12mm for Thumb Knob | WP-T5/016 |
| 17 | 1 | Switch T5, T5/EURO & T5EL V2 | WP-T5E/017 |
| 18 | 1 | Bottom Bearing 35mm x 17mm x 10mm 6003 | WP-T5/018 |
| 19 | 2 | Screw Self Tapping 4mm x 20mm Torx | WP-T5/019 |
| 20 | 1 | Bearing Cover for Top Bearing | WP-T5/020 |
| 21 | 2 | Machine Screw Cheese M4 x 89/45mm Pozi | WP-T5/021 |
| 23 | 1 | 2 Core Cable c/w Gland with Plug 240V UK T5 V2 | WP-T5/023A |
| | 1 | 2 Core Cable with Plug 115V UK T5L | WP-T5L/023 |
| | 1 | 2 Core Cable with Plug 230V Euro T5/EURO | WP-T5EURO/023 |
| 24 | 1 | Cable Guard | WP-T5/024 |
| 25A | 1 | Switch Cover V2 | WP-T5/025A |
| 26A | 1 | Screw Self Tapping 4mm x 25mm Torx | WP-T5/026A |
| 28 | 1 | Cable Clamp | WP-T5/028 |
| 29A | 1 | Field Complete 240V T5E & T5/EURO V2 | WP-T5E/029A |
| | 1 | Field Complete 115V T5EL V2 | WP-T5EL/029A |
| 30 | 1 | Deflector | WP-T5/030 |
| 31A | 1 | Armature 240V with Fan T5 & T5/EURO V2 | WP-T5E/031A |
| | 1 | Armature 115V with Fan T5EL V2 | WP-T5EL/031A |
| 32 | 1 | Carbon & Holder 240V T5 & T5/EURO (2 sets) | WP-T5E/032 |
| | 1 | Carbon & Holder 115V T5EL (2 sets) | WP-T5EL/032 |
| 33 | 2 | Brush Clamp | WP-T5/033 |
| 34 | 1 | Guide Rods 8mm x 300mm (pair) | ROD/8x300 |
| 35A | 1 | Top Bearing 8mm x 22mm x 7mm 6082RSI V2 | WP-T5/035A |
| 36 | 1 | Slotted Round Nut | WP-T5/036 |
| 37 | 1 | Collet Nut <05/2005 | CLT/NUT/T5 |
| 38 | 1 | Threaded Pin M5 x 40mm Revolving Guide | WP-T5/038 |
| 39A | 1 | Collet & Nut Set 6.35mm >05/2005 | CNS/T5/635 |
| | 0 | Collet & Nut Set 6.0mm >05/2005 | CNS/T5/6 |
| | 0 | Collet & Nut Set 8.0mm >05/2005 | CNS/T5/8 |
| 40 | 1 | Spanner 17mm A/F | SPAN/17 |

| T5 V2 - SPARE PARTS LIST | | | v11.0 07/2017 |
|---------------------------------|-------------|--|----------------------|
| No. | Qty. | Desc. | Ref. |
| 41 | 6 | Screw Self Tapping 4mm x 16mm Torx | WP-T5/041 |
| 42 | 2 | Locking Washer B4 | WP-T5/042 |
| 44 | 1 | Beam Trammel for 8mm Rod | BEAM/005 |
| 45 | 1 | Guide Bush 20mm Diameter | GB20 |
| 46 | 0 | Parallel Side Fence Complete with Micro Adjuster | WP-T5/046 |
| 47 | 1 | Parallel Side Fence Casting >05/2005 | WP-T5/047A |
| 48 | 1 | Micro Adjuster Knurled Knob >05/2005 | WP-T5/048A |
| 49 | 1 | Side Fence Cheeks (set) >05/2005 | WP-T5/049A |
| 50 | 1 | Phenolic Base Plate Slider | WP-T5/050 |
| 51 | 4 | Machine Screw Cheese M5 x 10mm Slot | WP-SCW/50 |
| 52 | 4 | Washer 5.3mm x 10mm x 1mm | WP-T5/052 |
| 53 | 1 | Scale | WP-T5/053 |
| 55A | 1 | Speed Control Circuit Board 240V T5 & T5/EURO V2 | WP-T5E/055A |
| | 1 | Speed Control Circuit Board 115V T5EL V2 | WP-T5EL/055A |
| 56 | 1 | Speed Control Dial | WP-T5E/056 |
| 57 | 1 | Insertion Socket | WP-T5/057 |
| 58A | 1 | Conductor Lead Switch to Speed Control V2 (Pair) | WP-T5/058A |
| 60A | 1 | Spring for Spindle Lock V2 | WP-T5/060A |
| 61A | 1 | Spindle Lock Body V2 | WP-T5/061A |
| 62 | 1 | Spindle Lock Plate | WP-T5/062 |
| 63A | 1 | Screw 4mm x 8mm Torx | WP-T5/063A |
| 64A | 1 | Washer 20mm x 8mm x 2mm Csk for Column V2 | WP-T5/064A |
| 65 | 1 | Machine Screw Csk M5 x 10mm Slot | WP-T5/065 |
| 66 | 1 | Plunge Column Spring | WP-T5/066 |
| 67 | 1 | Brass Ferrule for Spring | WP-T5/067 |
| 68 | 2 | Machine Screw Countersunk M5 x 10mm Slot | WP-SCW/13 |
| 69A | 1 | Rubber Sleeve V2 | WP-T5/069A |
| 70 | 1 | Lead Field to Speed Control (Red x 90mm) | WP-T5/070 |
| 71 | 1 | Lead Field to Speed Control (Red x 120mm) | WP-T5/071 |
| 72 | 1 | Lead Brush to Field (Blue x 90mm) | WP-T5/072 |
| 73 | 1 | Lead Brush to Field (Blue x 130mm) | WP-T5/073 |
| 74A | 1 | Dust Extraction Spout V2 | WP-T5/074A |
| 75 | 1 | Grip Knob Direction Arrow | WP-T5/075 |
| 76 | 3 | Machine Screw Csk M4 x 10mm Pozi | WP-SCW/48 |
| 77 | 0 | Side Fence Complete without Micro Adjuster | WP-T5/077 |
| 78A | 1 | Side Fence Stud M8 x 100mm >05/2005 | WP-T5/078A |
| 79 | 1 | Side Fence Washer 24mm x 12mm x 1.6mm | WP-T5/079 |
| 80 | 1 | Side Fence Half Nut Hex M8 | WP-T5/080 |
| 81 | 1 | Side Fence Circlip 12mm | WP-T5/081 |
| 82 | 1 | Side Fence Micro Adjuster Casting | WP-T5/082 |
| 83 | 1 | O Ring 6mm x 1.5 V2 | WP-T5/083 |
| 84 | 1 | Junction Block V2 | WP-T5/084 |
| 85 | 2 | Screw M3 x 8 Pan V2 | WP-T5/085 |
| 86 | 2 | Washer 3mm V2 | WP-T5/086 |
| 87 | 1 | Magnetic Disk V2 | WP-T5E/087 |
| 88 | 1 | Spindle Lock Button V2 | WP-T5/088 |
| 89 | 1 | Spindle Lock Housing V2 | WP-T5/089 |
| 90 | 1 | Manual | MANU/T5 |

T5 V2 - SPARE PARTS LIST

v11.0 07/2017

