




Combination Angle Gauge A/GAUGE



INST/A/GAUGE v2.0

Please
read carefully
before use

COMBINATION ANGLE GAUGE REF. A/GAUGE

Thank you for purchasing this product, which should give lasting performance if used in accordance with these instructions.

The following symbols are used throughout these instructions.



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions.

INTENDED USE

This product is intended for use as a gauge for measuring and marking external and internal angles directly from the clearly marked scale.

SAFETY

Please read and understand these instructions before use.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

The attention of UK users is drawn to The Provision and Use of Work Equipment Regulations 1998, and any subsequent amendments.

Users must be competent in using woodworking equipment before using our products.

ITEMS REQUIRED

- Pencil.

TECHNICAL DATA


The gauge is made of anodised aluminium. Alfa (α°) is read on the left side of the scale and Beta (β°) on the right.

$$\beta = \frac{360^\circ - (2\alpha)}{2}$$

OPERATION



The Combination Angle Gauge is adjusted by loosening the knob on the scale. Place the gauge where necessary for measuring the angle required, and adjust to suit.



trend[®]
routing technology

ENVIRONMENTAL PROTECTION

Recycle raw materials instead of disposing as waste.

Packaging should be sorted for environmental-friendly recycling. The product and its accessories at the end of its life should be sorted for environmental-friendly recycling.

GUARANTEE

All Trend products are guaranteed against any defects in either workmanship or material, except products that have been damaged due to improper use or maintenance.

© Trend Machinery & Cutting Tools Ltd. 2012 E&OE
® All trademarks acknowledged

Trend Machinery & Cutting Tools Ltd.
Odhams Trading Estate St Albans Road
Watford WD24 7TR England
Tel: 0044(0)1923 249911
technical@trendm.co.uk
www.trend-uk.com




RS 28982
Stockholding
& Supply




RECYCLABLE

Place the gauge on the work-piece and mark the halved angle as shown below.



The diagram below shows the position of the three angles the gauge measures, which can be read from the scale.



Regularly check knobs, handles and locking nuts are tight.

SPARE PARTS

Please use only Trend original spare parts.

MAINTENANCE

The accessory has been designed to operate over a long period of time with minimum of maintenance. Continual satisfactory operation depends upon proper tool care and regular cleaning.

Cleaning

- Keep the grooves and knob threads clear of sawdust.
- Regularly clean with a soft cloth.

Lubrication

- Your accessory requires no additional lubrication.

Storage

- Always return product to its packaging after use, or hang it on a wall hook.



Our policy of continuous improvements mean that specifications may change without notice. Trend Machinery & Cutting Tools Ltd. cannot be held liable for any material rendered unusable, or for any form of consequential loss.

