

i INST

DIAMOND CROSS

FTS/KS

Diamond Cross

Fast Track Knife

Sharpener



INST/FTS/KS v1.1

trend[®]
routing technology

Please read carefully before use

FAST TRACK KNIFE SHARPENER REF. FTS/KS

Thank you for purchasing this product.
The following symbols are used throughout these instructions.



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions.

INTENDED USE

This accessory is designed to be used for the sharpening of knives.

SAFETY

Please read and understand these instructions before use.

Before attempting to use the FTS/KS, Please understand that handling knives can be dangerous.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

Users must be competent in using woodworking equipment before using our products.

Please keep children and visitors away from tools and work area. Consider working environment before using tools. All tools have residual risk, so must therefore be handled with caution.

Ensure working position is comfortable.



All cutting edges are very sharp and care must be taken to prevent injury. Never sharpen blades towards the hand or body.

Ensure all tools are used correctly, maintained properly and stored carefully.

Knife Grip




Always hold your knife in your dominant hand with a light grip.

ITEMS REQUIRED

- Knife.
- Flat surface.


ITEMS ENCLOSED & DESCRIPTION OF PARTS

- A. Knife sharpener main body **x1**
- B. 220 Grit diamond stone **x1**
- C. Leather strop front **x1**
- D. Leather strop rear **x1**
- E. Strike plate **x1**
- F. Machine screw M4 x 10mm **x2**




OPERATION

Setting Up - Important



- The flat of the blade must remain against the front stop during stroke. The magnets will help with this.




- DO NOT allow the blade to come away as it will drop into the slot.


Worktop Technique



- Resting the knife sharpener on a worktop, hold top of handle with your non-dominant hand. Hold knife loosely, take four sharpening strokes.



- Rotate knife sharpener 180 degrees, slot facing the opposite direction.



Repeat same number of full strokes. When edge is achieved, see Stropping Technique.

ENVIRONMENTAL PROTECTION

Recycle raw materials instead of disposing as waste.

Packaging should be sorted for environmental-friendly recycling.

The product and its accessories at the end of its life should be sorted for environmental-friendly recycling.

GUARANTEE

All Trend products are guaranteed against any defects in either workmanship or material, except products that have been damaged due to improper use or maintenance.

© Trend Machinery & Cutting Tools Ltd. 2018 E&OE

® All trademarks acknowledged

Trend Machinery & Cutting Tools Ltd

Odhams Trading Estate St Albans Road
Watford WD24 7TR England

Tel: 0044(0)1923 249911

technical@trendm.co.uk


www.trend-uk.com




RECYCLABLE



Handheld Technique




- Hold the knife sharpener in your non-dominant hand. Insert the knife.



- Take four sharpening strokes the full length of the blade in the direction of the arrow.




- Rotate the Knife Sharpener over so that the slot faces down.




- Repeat same number of full sharpening strokes.

 Always repeat the same number of strokes per side of knife.

Stropping Technique



- When sharp edge is achieved, rotate knife sharpener so leather strop is face up and wipe blade edge across strop.



- Turn knife over and wipe both sides across leather strop.


NOTE

The larger the blade and the more material needing to be removed the longer the process will take. Depending on how blunt the knife is, it may take 5-10 minutes work to regrind and establish new bevels to the blade edge. Afterwards it will only take 3 or 4 strokes on both sides to re-establish the edge.


 Consider working environment before using tools.

 Ensure working position is comfortable.

Removing Diamond Stones



Holding the ends of the diamond stone, unclip it from the front plate magnet.



Slide the diamond stone up or out of the side.

After use, store product safely.

MAINTENANCE

Please use only Trend original spare parts and accessories.

Continual satisfactory operation depends upon proper tool care and regular cleaning.

Cleaning

- Wipe occasionally with a damp cloth.

- Not dishwasher friendly.

- To clean diamond stones use a cleaning block Ref. DWS/CB/A.

Lubrication

- Accessory requires no additional lubrication.

Storage

- Always return product to its packaging after use.

- Store in a dry, clean environment.

ACCESSORIES

Please only use Trend accessories. See website for details of other accessory stone grit types.