

TORCH BATTERY SAFETY FITTING INSTRUCTION



WARNING

Check for correct polarity (+/-)

KEEP OUT OF REACH OF CHILDREN.

Do not swallow. If swallowed, seek medical advice at once. Do not disassemble, recharge or dispose of in a fire. Do not mix used and new batteries, different brands or types: may explode, leak and cause damage. Remove the battery before storing the instrument, store separately to avoid short circuit. Remove exhausted and expired batteries promptly. Please dispose of batteries properly.



Remove battery safety tab before use.

Battery Fitting



For TCH/HA/H10, TCH/PE, TCH/AT



For TCH/HA/H20



trend[®]
routing technology

IMPORTANT



Caution LEDs are extremely bright and direct exposure to eyes may cause injury. For eye protection, do not look directly into the light.



WARNING!
Intense beam of light.



INST/TCH/BAT v1.0

© Trend Machinery & Cutting Tools Ltd. 2018

Trend Machinery & Cutting Tools Ltd.

Odhams Trading Estate St Albans Road
Watford WD24 7TR England

Tel: 0044(0)1923 249911

technical@trendm.co.uk

www.trend-uk.com



RECYCLABLE

