


H/JIG/B - SPARE PARTS DIAGRAM

V2.0 02/2011

Please use only Trend original spare parts.



H/JIG/B - SPARE PARTS LIST			V2.0 02/2011
No.	Qty.	Desc.	Ref.
1	1	Jig Body Short (Top)	WP-HJ/B/01
2	1	Jig Body Long (Bottom)	WP-HJ/B/02
3	1	Swivel Plate	WP-HJ/B/04
4	3	Edge Stop Complete	WP-HJ/B/05
5	4	Machine Screw Countersink M5 x 10mm for Adjustment Plate	WP-HJ/B/06
6	3	Machine Screw Dome M5 x 8mm for Connecting Plate	WP-HJ/B/07
7	1	Connecting Plate	WP-HJ/B/08
8	1	Adjustment Plate	WP-HJ/B/09
9	1	T-Handle Hex Key 3mm A/F	HK/T/03
10	1	Guide Bush 16mm Dia.	GB160
11	6	Plastic Spacer	WP-HJ/08
12	3	Bradawl	WP-HJ/09
13	1	Nut Square M5	WP-NUT/07
14	1	Machine Screw Csk M5 x 16mm Pozij [®]	WP-SCW/11
15	1	Carry Case	CASE/HJ/A
16	1	Manual	MANU/HJ/B