



WIRING DIAGRAM T9E & T9/EURO

v1.0 10/2001

Item	Qty	Description	Ref.
1	1	Cable 2 Core With Plug 230V UK (T9E)	WP-T9/006
	1	Cable 2 Core With Plug 230V EURO (T9/EURO)	WP-T9EURO/006
2	1	Switch 230V (T9E)	WP-T9E/035
3	1	Speed Control Circuit Board 230V (T9E)	WP-T9E/004
4	1	Field Complete 230V (T9E)	WP-T9E/014
5	1	Carbon Brush 230V - One Pair (T9E)	WP-T9E/007
6	2	Brush Holder	WP-T9/008
7	2	Lead - Cable Block To Switch (Brown x 330mm)	WP-T9/094
8	2	Lead - Switch To Cable Block (Blue x 390mm)	WP-T9/093
9	2	Cable Block	WP-T9/071
10	2	Lead - Brush Holder To Field (Red x 115mm)	WP-T9/099
11	-	Lead - Cable Block To Speed Control (Brown x 175mm)	-
12	-	Lead - Cable Block To Speed Control (White x 155mm)	-
13	-	Lead - Cable Block To Field (Blue x 215mm)	-
14	-	Lead - Cable Block To Field (Black x 140mm)	-



RS 28842
Stockholding
& Supply

Trend Machinery & Cutting Tools Ltd.
 Odhams Trading Estate St Albans Road Watford WD24 7TR
 Tel: 01923 212928 Fax: 01923 228656
 Email: mailserv@trendm.co.uk
 www.trendmachinery.co.uk

© Copyright Trend 2001. No part of this publication may be reproduced, stored or transmitted in any form without prior permission. Our policy of continuous improvement means that specifications may change without notice. Trend Machinery and Cutting Tools cannot be held liable for any material rendered unusable or any form of consequential loss. E&OE. © All trademarks acknowledged.



DIAGW/T9E v1.0